




INSTALL GUIDE



HIGH-PERFORMANCE
BI-LED
PROJECTORS

WARNING: By reading this document, you agree it is only to be used as an educational guide. Morimoto Lighting nor its distributors make guarantees on any finished results, nor are they to be held responsible for any damage, misuse, or personal injuries. Use at your own risk. If you are unable to clearly understand and adapt the information below, professional installation is recommended.

PACKAGE CONTENTS



1 X MLED PROJECTOR



1 X DRIVER



1 X HARDWARE BAG

ASSEMBLY PROCESS

Pass the threaded shaft of the projector through silicone washer and then through the bulb opening in the headlight reflector. Then, fit the three-prong H4 adapter. Finally, add the metal lock nut and tighten until snug, being sure to not over-tighten.


LOCK NUT



SILICONE WASHER



HEADLIGHT REFLECTOR




PROJECTOR

H4 ADAPTER




WIRING SCHEMATIC



INSTALLING SHROUDS

Fitting compatible shrouds to the M LED is simple. Add a few small dabs of two-part epoxy such as JB Weld to the front of the lens holder (the frame holding the glass lens of the projector) and fit the shroud flush to that surface. We recommend using blue masking tape until the epoxy cures fully.

NOTE: As part of a projector retrofit, trimming shrouds to fit the housing is common and often required. For this, we recommend a belt sander and/or cutoff wheel.



*STYLE MAY VARY